

Thank You

Thanks for purchasing a DST mid-range pump-control ultrasonic sensor from us! We appreciate your business and your trust. Please take a moment to familiarize yourself with the product and this manual before installation. If you have any questions, at any time, don't hesitate to call us at 888-525-7300.

You can also find a full list of our product manuals at:

www.apgsensors.com/resources/product-resources/user-manuals

Table of Contents

- | | | |
|---------------------------|----------------------------|-------------------------------|
| 1. Description | 5. Installation Guidelines | 9. Repair Information |
| 2. How To Read Your Label | 6. Connecting to a DCR | 10. Hazardous Location Wiring |
| 3. Warranty | 7. Sensor Wiring | |
| 4. Dimensions | 8. General Care | |

1 Description

The DST series is APG's line of ultrasonic sensors used in conjunction with a DCR controller to give you a simplified, stand-alone system. The transmit and receive circuit is built into the sensor and digitally communicates the detected distance to the DCR controller. This allows the sensor to be separated from the DCR controller by up to 2000 feet (610 meters) with no signal loss.

2 How To Read Your Label

Each label comes with a full model number, a part number, and a serial number. The model number for your DST will look something like this:

▲ SAMPLE: DST-2421-C10

The model number tells you exactly what you have. You can also call us with the model, part, or the serial number and we can help you.


You'll also find all hazardous certification information on the label.

3 Warranty

This product is covered by APG's warranty to be free from defects in material and workmanship under normal use and service of the product for 24 months. For a full explanation of our Warranty, please visit www.apgsensors.com/resources/warranty-certifications/warranty-returns/. Contact Technical Support to receive a Return Material Authorization before shipping your product back.

4 Dimensions

Dimensions: in./mm



DST Mid-Range Ultrasonic Sensor Installation Guide

DST-2421, DST-3431, DST-5111, DST-9421



Automation Products Group, Inc.
1025 W 1700 N Logan, UT 84321
www.apgsensors.com | phone: 888-525-7300 | email: sales@apgsensors.com

Part # 200851
Doc #9006501 Rev B

5 Installation Guidelines

Your DST should be installed in an area--indoors or outdoors--which meets the following conditions:

- Ambient temperature between -30°C and 60°C (-22°F to +140°F)
- Ample space for maintenance and inspection

Additional care must be taken to ensure:


- The sensor has a clear, perpendicular sound path to the surface being monitored.
- The sensor is mounted away from tank or vessel walls and inlets.
- The sound path is free from obstructions and as open as possible for the 9° off axis beam pattern.
- The sensor is tightened by hand to avoid cross-threading.

***Important:** For user interface guide and sensor configuration, see the DCR-1006A user manual.

! IMPORTANT: Refer to section 10 for Hazardous Location Wiring.

6 Connecting to a DCR

DCR-1006A wiring terminals are accessible by unscrewing and then lifting off the front (top) face.



7 Sensor Wiring

DST Sensor	DST	Standard Cable	Micro-Connector
+	+	Red	Pin 1 (Brown)
-	-	Black	Pin 3 (Blue)

! NOTE: For programming the DCR-1006A controller, please see the DCR-1006A User Manual.

8 General Care

Your ultrasonic sensor is very low maintenance and will need little care as long as it was installed correctly. However, in general, you should periodically inspect your DST sensor to ensure the sensor face is free of any buildup that might impede the function of the sensor. If sediment or other foreign matter becomes trapped on the sensor face, detection errors can occur.

If you need to remove the sensor, be sure to store it in a dry place at a temperature between -40° and 180° F.

9 Repair Information


If your DST ultrasonic sensor needs repair, contact us via email, phone, or online chat on our website. We will issue you an RMA number with instructions.

- Phone: 888-525-7300
- Email: sales@apgsensors.com
- Online chat at www.apgsensors.com

10 Hazardous Location Wiring

Installation In Class I Division 2 Groups C and D
Class I Zone 2 A Ex nA IIB

REVISIONS					
ZONE	REV	DESCRIPTION	CHANGE ORDER	DATE	APPROVED
-	B1	Add French Translation	CO-	2259	4-8-15 K. REID



- Install in accordance with Section 18 of the CEC or Article 500 of the NEC.
- CSA listed or NRTL/UL listed conduit seal at location A & B.
- The cable is potted into the sensor and runs continuously from the sensor through the Hazardous area and into the Non-Hazardous area.
- Electrical equipment connected to associated apparatus should not generate more than 250 V rms.
- Tampering or replacement with non-factory components may adversely affect the safe use of the system.
- WARNING- DO NOT DISCONNECT WHILE CIRCUIT IS ALIVE UNLESS AREA IS KNOWN TO BE NON-HAZARDOUS

AVERTISSEMENT-NE PAS DEBRANCHER TANT QUE LE CIRCUIT EST SOUS TENSION, A MOINS QU'IL NE S'AGISSE D'UN EMPLACEMENT NON DANGEREUX

- WARNING - POTENTIAL ELECTROSTATIC CHARGING HAZARD - Clean only with a damp cloth

AVERTISSEMENT - surface non conductrice du boîtier peuvent être facturés par MEDIA non conductrice , CLEAN avec un chiffon humide

PROPRIETARY AND CONFIDENTIAL THIS DRAWING IS THE PROPERTY OF AUTOMATION PRODUCTS GROUP, INC. LOGAN, UTAH AND MAY NOT BE USED, REPRODUCED, PUBLISHED, OR DISCLOSED TO OTHERS WITHOUT WRITTEN CONSENT OF THE COMPANY. IF LOANED, IT IS SUBJECT TO RETURN UPON DEMAND AND MAY NOT BE USED IN ANY WAY DIRECTLY OR INDIRECTLY DETRIMENTAL TO THE COMPANY. <small>Form 9002512 Rev B</small>	UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES AND TOLERANCES ARE AS FOLLOWS: TOLERANCE ON ANGLE: ±1° 2 PLACES: ±.01" 3 PLACES: ±.005" INTERPRET DIMENSIONS AND TOLERANCES PER ASME Y14.5M 1994 (R1999) THIRD ANGLE PROJECTION 	APPROVALS	DATE	1025 West 1700 North Logan, Utah USA Automation Products Group, Inc. 888.525.7300		
		DEPT T. BRUNSON	01/11/02		Hazardous Location Installation Drawing IRU Series and DST Series Sensors	
		CHKD K. REID	01/11/02			
		APVD K. REID	01/11/02			
CONTRACT		SIZE C	CAGE CODE 0Z430	PART NO	DOCUMENT NO 9003066	REV B1
MATL		SCALE NONE		DO NOT SCALE DRAWING		SHEET 1 OF 1